

Changing User Codes

With the **system disarmed** you are ready to begin.

Type [*][5][**master code**] , this will put you in the user programming mode.

To add a new user such as user #14:

Type [1][4]

Type [*] to select access code

, then type [**user 14's 4 digit code**],

Type [#] to exit one level

To change a user such as user #14 :

Type [1][4]

Type [*] to select access code

, then type [**user 14's new 4 digit code**],

Type [#] to exit one level

To delete a user such as user #14 :

Type [1][4]

Type [*] to select access code

, then type [*] to delete that user,

Type [#] to exit one level

